



Trail Camera



Instruction Manual

Model #: 119239C

07-14

Page Index

Introduction	5
Parts & Controls Guide	6-7
Battery and SD Card Installation	8
Date & Time Imprint Feature	9-10
Power On	10
Set Up	10-11
Viewing the Photos	12
<i>Glossary</i>	13
<i>Technical Specifications</i>	14
<i>Troubleshooting/FAQ</i>	15-17

IMPORTANT NOTE

Congratulations on your purchase of one of the best trail cameras on the market! Simmons is very proud of these cameras and we are sure you will be pleased with yours as well. We appreciate your business and want to earn your trust. Please refer to the notes below and the instructions in this manual to ensure that you are completely satisfied with this product.

If your Simmons Trail Cam does not seem to be functioning properly or if you are having photo/video quality issues, please check the Troubleshooting/FAQ section on pages 15-17.

Problems are often due to something simple that was overlooked, or require only changing one setting to solve.

If your problem continues after trying the solutions in the Troubleshooting/FAQ section, **please call Simmons Customer Service at (800) 423-3537.** In Canada, call (800) 361-5702.

Simmons recommends using 8 Energizer® Lithium AA batteries in this Trail Cam to obtain maximum battery life.

Do Not Mix Old and New Batteries

Do not mix battery types-use ALL lithium or ALL alkaline.

Rechargeable batteries are not recommended.

Simmons recommends using SanDisk® SD and SDHC Cards (up to 16GB capacity) in this Trail Cam.

INTRODUCTION

Congratulations on your purchase of a Simmons Digital Trail Camera. This camera, with its weatherproof, rugged construction, is designed to record animal activity in the outdoors. Your Trail Cam features a compact, portable size and an extra long battery life.


Main Features:

- 1.3 MP digital sensor, 2MP image resolution
- Compact Size
- Trigger Time=1.5 seconds or less
- Automatic IR Filter
- 12 Night Vision LEDs
- Supports up to 16 GB SD Card
- Date, Time & Moon Phase Imprint
- Auto Exposure
- Auto White Balance
- Power Supply: 4 or 8 AA batteries (lithium or alkaline)
- Mounting Strap Supplied
- Weatherproof

Parts and Controls Guide



Front of Camera




IR LED Array Detail


Parts and Controls Guide



Battery
Compartment
(note orientation for
correct polarity)



Power
Switch



BATTERY INSTALLATION

To maximize battery life, you should install a full set of 8 AA lithium (for longest life) or alkaline batteries. The camera may also be powered by just four batteries installed in the first slots only (see photo). Battery life will be shorter with 4 batteries, but the camera will operate normally.

NOTE: Always set the power switch to the OFF position when installing or removing batteries.

Please make sure the batteries are inserted correctly, as indicated inside the battery compartment. Incorrect voltage or polarity (+/-) will damage the camera.

Do not mix old and new batteries.

Do not mix battery types-use ALL lithium or ALL alkaline.

Rechargeable batteries are not recommended.

SD CARD INSTALLATION

Memory

Your Digital Trail Camera has a memory card slot, to accept SD cards up to 16 GB max. capacity (*not included*). When the SD card is full, the camera will stop capturing images.

Inserting an SD card

- Make sure the power switch is in the **OFF** position whenever adding or removing memory.
- Insert an SD card into the card slot completely and oriented correctly as shown by the icon above the slot (label up, contacts facing down and notched corner on the right).
- To remove the SD memory card, depress the SD card and pull out the card gently.

Using a new, blank SD card is recommended. If the SD card has been used in another device, please make sure to format it (*FAT16*) using your computer before you set the camera to capture photos. New cards are ready to use straight from the package.

DATE AND TIME IMPRINT FEATURE

Your Digital Trail Camera will automatically imprint the date, time and moon phase on each photo it captures, based on the initial date and time data in a text file you can generate and save on the SD card, as described below. If no text file with date/time is found on the card when the camera is turned on, only “Simmons” will be imprinted on the photos.



07-15-2014 09:36:18

Requirements:

- A PC computer with an internal SD card slot, or an external USB card reader.
- The “Timetool” application (Windows only), which is provided by the camera-see details below.

Steps:

1. Switch the Trail Camera to “ON”. Insert a new SD card in the camera’s card slot. The “Timetool.exe” software will be automatically saved to the card.
2. Turn off the camera and remove the SD card. Insert the card in your computer’s SD card slot or a compatible USB connected card reader. View the SD card contents-double click to open the file “timetool.exe”.
3. Click “Update” in the Timetool window to automatically fill in the date and time from your computer’s clock. If this is not the correct date and time, click “Edit” and make changes as needed.
4. Click the “...” button above Cancel and select the SD card location (drive letter). Or, if you know the drive letter for the SD card (e.g. “D:\”), change the “A” in the white box to the correct letter.



5. Once the date/time data is correct and you've selected your SD card location, click OK to save the text file.
6. Remove the SD card (eject it first if necessary) and insert it into your Trail Cam (label side up as previously described). The date and time data will be automatically loaded into the camera, and the text file (txt) will be deleted. **It is important to get the card from computer to camera as soon as possible to ensure the initial time is still accurate.**

Note for Mac (OSX) users: although the Timetool software is Windows only, you can create a compatible file using any application that supports plain text files (.txt format). Using this app, type the current date and time using this format: "TIME"YYYYMMDDHHMM (Include the word "TIME" with quote marks. Do not add spaces, hyphens or slashes). For example, "TIME"201407171038 represents July 17th, 2014 at 10:38 AM. Save this as a .txt file to your SD card, naming the file "TIMESYNC".

POWER ON

After inserting batteries and an SD card (w/date & time file at your option), slide the power switch to the **On** position. The PIR indicator (red LED) is used to warn of problems with the SD card or battery.

- If the red light flashes rapidly for 10 seconds, there is a problem with the SD card. Check the card (make sure it's inserted correctly and protect switch is not locked) or try a different card.
- If the red light stays on for 20 seconds, the battery level is low-insert fresh batteries.

To capture photos of activity in the area you choose to locate your Simmons Trail Camera, follow the steps listed below in "SET UP":

SET UP

1. Mount the Camera

It is recommended that you mount the camera about 4 or 5 feet (1.2~1.5 meters) off the ground, with the camera pointed at a slight downward angle. It's best to avoid mounting the camera facing east or west as the rising and setting of the sun could produce false triggers and overexposed images. Clear branches and other debris away from the front of the

camera so as not to block the camera lens or PIR sensor.

To mount the camera in place, insert the strap through the strap slots on the rear housing. Wrap the strap around the mounting surface. Secure the strap and tighten the buckle in order to secure the camera.

Make sure that both of the camera's latches are securely locked in place, to ensure proper weather resistance.


2. Power On the Camera

If both SD card and batteries are good, the camera will begin taking photos 10 seconds after you move the switch to "ON", whenever it is triggered by the PIR sensor's heat/motion detection. Each time the PIR sensor is triggered, the camera will take a new photo following a 10 second delay. For the first three minute of operation, the PIR indicator will glow for about 3 seconds when it senses animal or human activity within the PIR coverage area. See "Test the Coverage Area" below.

3. Test the Coverage Area

One of the Trail Camera's most useful features is the ability to test the coverage area.

- After mounting the camera, open the front housing and slide the Power switch to the "ON" position.
- The PIR indicator LED below the lens will glow for 3 seconds when you trigger the PIR by entering the coverage area.
- Adjust the camera position as needed and repeat the test until the desired coverage area is achieved.
- After three minutes, the PIR indicator will not glow when you are in the coverage area (to avoid being seen by animals or potential thieves. The camera is now "sleeping" and waiting for the PIR sensor to trigger the an image capture.
- Maximum PIR sensor range is approx. 13 meters (42 ft).



4. Secure the Camera

A standard padlock may be used in the camera's lock hole to secure it and prevent theft.

VIEWING THE PHOTOS

After your camera has been operating for awhile, you will of course want to review the photos it has been capturing. This can be done by either of two methods, according to your preference or the availability of accessory equipment:

Using an SD Card Reader

1. Push the SD card in slightly to release it, then pull it out of the camera gently.
2. Put the SD card into a USB connected SD card reader (either a dedicated SD card reader or "multi-card reader" that features slots for different types of memory cards, including SD) or the SD card slot on your computer if it has one.
3. The SD card or card reader should appear on your desktop or list of connected "drives". Double click it to view or download the photo files (.jpg) on the SD card.

GLOSSARY

PIR (Passive Infrared Sensor): Senses motion like a typical security motion detector. Requires infrared energy (heat) in addition to motion to trigger the sensor to help limit detection to live subjects (rather than leaves, etc).

Moon Phase: The trail cams have a feature which imprints a moon phase stamp on each photo for reference.

IR Flash: Also called IR LED Array. This is a “night vision” feature, which emits a burst of infrared light, invisible to the human eye. Especially useful for night photos when a visible flash may be undesirable.

Battery Life: Time that camera will function in the field. Dependent on ambient temperature, number of images taken and number of times the IR flash fires. When the battery voltage drops below 4.5v, the IR flash stops firing. When battery voltage is below 3.5v, the camera stops working.

Mass Storage: Connect the camera with a USB cable to a computer, press the “SETUP” button, and the computer can access the contents of the SD card. The camera is automatically recognized as an “external drive”, without the need to install special drivers. *(Win 98 and older operating systems are not supported. Mac OSX is also compatible-the camera will appear on your desktop as an external storage device or “disk”).*

TECHNICAL SPECIFICATIONS

Model Number	119239C
Image Sensor Type	1/4 Inch CMOS
Sensor Resolution	1.3 Megapixels
Effective Focal Length	7.6 mm
Lens Aperture	f/2.0
IR Filter	Automatic IR Filter
PIR Sensor	Yes
Trigger Speed	<1.5 seconds
Number of IR LED	12 LEDs
Max Night Vision Lighting Distance	30 feet
Storage	SD Card, up to 16 GB Capacity
PIR Indicator	Yes
Image Resolution	2 MP*
File Format	JPEG
Date/Time Imprint	Yes (initial data input via text file on SD card)
Moon Phase Imprint	Yes
Exposure	Auto
White Balance	Auto
Power Supply	4 or 8 AA cell batteries (alkaline or lithium)
Power Consumption	<200ma (<600ma w/LED flash)
Average Continuous Running Time	approx 2 mo. (+/- 1 mo. depending on # of photos using LED flash)
Water Resistant	Yes

*2MP resolution via software interpolation

Troubleshooting / FAQ

Battery life is shorter than expected

1. Battery life will vary with operating temperature and the number of images taken over time.
2. Check to make sure you have used new alkaline or lithium batteries. **Simmons recommends using 8 Energizer® Lithium AA batteries in this Trail Cam to obtain maximum battery life.**
3. Make sure that you are using a good quality name brand SD card in your camera. **Simmons recommends SanDisk® brand SD Cards up to 16GB.** Our experience indicates that poor quality SD cards can sometimes reduce your trail cam battery life.

Camera stops taking images or won't take images

1. Please make sure that the SD card is not full. If the card is full, the camera will stop taking images.
2. Check the batteries to make sure that they are new alkaline or lithium AA batteries. ***See note above about short battery life.***
3. Make sure that the camera power switch is in the "ON" position and not in the "OFF" position.
4. Make sure that you are using a good quality SD card in your camera. **Simmons recommends SanDisk® SD Cards up to 16GB.**
5. If the SD card has its write protect switch in the lock position, the camera will not take images.
6. If you have used an SD card in another device before inserting it in your trail cam, you might want to try formatting the card on your computer (make sure you have backed up any important files first, as formatting will erase all previous files). In some cases, other devices may change the formatting of the SD card so that it will not work properly with the Trail Cam.

Camera won't power up

1. Make sure that you have installed at least 4 batteries in the battery compartment. **Simmons recommends using 8 Energizer® Lithium AA batteries in this Trail Cam.**
2. Make sure that the batteries are installed correctly, observing proper polarity. Always place the negative (flat) end of each

Troubleshooting / FAQ

battery in contact with the spring tab side of its slot inside the camera.

Do not mix old and new batteries.
Do not mix battery types-use ALL lithium or ALL alkaline.
Rechargeable batteries are not recommended.

Still Photo and/or Video Quality Problems

1. ***Night photos appear too dark***
 - a. Try using a set of new batteries. The flash will stop operating near the end of the battery life.
 - b. You will get the best results when the subject is within the ideal flash range, no farther than 30' from the camera. Subjects may appear too dark at greater distances.
2. ***Daytime photos appear too dark***
 - a. Make sure that the camera is not aimed at the sun or other light sources during the day, as this may cause the auto exposure to produce darker results.
3. ***Night photos appear too bright***
 - a. You will get the best results when the subject is within the ideal flash range, no closer than 10' (3m) from the camera. Subjects may appear too light at closer distances.
4. ***Daytime photos appear too bright***
 - a. Make sure that the camera is not aimed at the sun or other light sources during the day.
5. ***Red, green or blue color cast***
 - a. Under certain lighting conditions, the sensor can become confused resulting in poor color images.
 - b. If this is seen on a consistent basis, then the sensor may need servicing. Please contact Simmons customer service.

Photos Do Not Capture Subject of Interest

1. Try to set your camera up in an area where there is not a heat source in the camera's line of sight.
2. In some cases, setting the camera near water will make the camera take images with no subject in them. Try aiming the

Troubleshooting / FAQ

camera over ground.

3. Try to avoid setting the camera up on small trees that are prone to being moved by strong winds.
4. Remove any limbs which are right in front of the camera lens.

PIR Sensor LED Flashes/Doesn't Flash

1. For the first three minutes after the camera is switch on, the PIR Indicator LED on the front of the camera will flash for 3 seconds whenever it senses motion. This is for setup purposes only and will help the user aim the camera.
2. During use, the LED will not flash when the camera takes an image. This is to help keep the camera hidden from game.

Time/Date Imprint is Not Accurate

1. If you let any significant amount of time elapse between setting and saving the current time on the SD card using your computer (*following the Timetool directions on pg. 9*) and inserting it back into the camera, the time will be off by that amount. If you don't put the card back into the camera until two days after you saved the text file on it with the time & date, the camera will "think" the current date is still the same as it was two days ago, and the imprint on your photos will be off by that much.

ONE-YEAR LIMITED WARRANTY

Your Simmons® product is warranted to be free of defects in materials and workmanship for one year after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than a Simmons Authorized Service Department.

Any return made under this warranty must be accompanied by the items listed below:

1. A check/money order in the amount of \$10.00 to cover the cost of postage and handling
2. Name and address for product return
3. An explanation of the defect
4. Proof of Date Purchased
5. Product should be well packed in a sturdy outside shipping carton, to prevent damage in transit, with return postage prepaid to the address listed below:

IN U.S.A. Send To:

Simmons Optics
Attn.: Repairs
9200 Cody
Overland Park, Kansas 66214

IN CANADA Send To:

Simmons Optics
Attn.: Repairs
140 Great Gulf Drive, Unit # B
Vaughan, Ontario L4K 5W5

This warranty gives you specific legal rights.
You may have other rights which vary from country to country.
©2014 B.O.P.

Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.

FCC Compliance Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device does not contain any user-serviceable parts. Repairs should only be made by an Authorized Simmons repair center. Unauthorized repairs or modifications could result in permanent damage to the equipment, and will void your warranty and your authority to operate this device under Part 15 regulations.

The shielded interface cable which is provided must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.





For further questions or additional information please contact:

Simmons Optics
9200 Cody, Overland Park, Kansas 66214
(800) 423-3537 • www.simmonsoptics.com

©2014 B.O.P.